



Connecting the Explorer® 2100™/3100™ to a Stereo TV and Stereo VCR and DVD Player

Explorer 2100/3100



Cable Input



Back of DVD Player



Optional Connection

Note: This connection is optional and if used without the other audio/video connections, it will provide monoral audio.

Back of Stereo TV



Back of Stereo VCR