



Connecting the Explorer® 2200™/3200™/3250™ to a Stereo TV and Stereo VCR and DVD Player


Explorer 2200/3200/3250



Back of DVD Player




Back of Stereo TV



Optional Connection

Note: This connection is optional and if used without the other audio/video connections, it will provide monaural audio.



Back of Stereo VCR